Quick Start Guide

i6775

STEP 1 Check package contents

Make sure your phone's packaging includes the following:



STEP 2 Connect power to telephone base/ chargers

Plug the power adaptor into an electrical outlet not controlled by a wall switch, and the connector into the power jack on bottom of the telephone base/chargers.



NOTE:
- Use only the power adaptors supplied with your VTech telephone.

STEP 3 Battery installation

1. Align the two holes in the plug with the socket pins, then snap the plug into place. Place the battery in the compartment with the wires in the upper right corner.
2. Replace cover by sliding it upwards until it clicks into place.



STEP 4 Charge the battery

1. Place the handset in the base unit/chargers.
2. Charge the battery for at least 16 hours before first use.



STEP 5 Connect to phone line

Plug one end of the telephone line cord into the telephone line jack at the bottom of the telephone base. Then plug the other end of the cord into the wall telephone outlet.



STEP 6 Making and receiving calls

Making a call
- Press **TALK/FLASH** or **SPEAKER** and listen for dial tone.



- Dial the phone number.

-OR-
- Dial the phone number.
- Press **TALK/FLASH**.

Receiving a call

Press **TALK/FLASH**, **SPEAKERPHONE**, or any dialing key except **OFF**.



Hanging up

Press **OFF** or place the handset in its base/chargers.



Step 7 Set the clock

1. Press **TIME/SET** to listen to the current setting.
2. Press **TIME/SET** again to indicate changes needed.
3. Press **CHANGE** to change the day, hour, minute, or year.
4. When you hear the correct setting, press **TIME/SET** to advance to the next setting.

NOTE:
If you have caller ID service, the time will automatically be updated with the first incoming call after your program the year into the system.

Step 8 Record your outgoing announcement

1. Press **SETUP**, the system announces "*Announcement. Press **PLAY** or press **RECORD**. To continue setup, press **SETUP**.*"
2. Press **REC/MEMO** and speak toward the **MIC** on the base to record an announcement for up to 90 seconds.
3. Press **PLAY/STOP** ▶/■ (when finished recording).

NOTE:
For complete feature instructions, please refer to your user's manual.

IMPORTANT!

If your product is not working properly:
1. Refer to your user's manual.
2. Visit our website at www.vtechphones.com or www. vtechcanada.com in Canada.
3. Call our customer service at 1-800-595-9511 or 1-800-267 7377 in Canada.

96-006097-010-000
issue 0